

INKER & RASOR

CORROSION MITIGATION INSTRUMENTATION

P. O. Box 1667 San Bernardino, Ca 92412 TEL: (909) 890-0700 Fax: (909) 890-0736

PRODUCT INSTRUCTIONS

T-1 INSTRUCTIONS Prior to installation check parts list!

- Step 1. Install connecting hardware, binding post or other accessories into the holes in the T-1 test station terminal. Most Model T-1 CP Test Stations will come with three (3) binding posts installed.
- Step 2. Install Tinker & Rasor's exclusive "anti-spin" gasket. Remove protective paper from one side of gasket and place sticky side inside the terminal and press firmly. Remove the remaining protective paper cover from the gasket.
- Step 3. Place black nut over 1-1/2" OD test station riser. (custom color nuts available)
- **Step 4.** Thread the cables through bottom of the T-1 terminal.
- Step 5. Position the T-1 terminal to the desired alignment over the riser and press down firmly. The "antispin" gasket will seal the terminal to the riser. Tighten terminal to riser pipe with the large black nut while holding the terminal.
- Step 6. Attach cables as required.

To unlock the Top: Twist the Top counter-clockwise to remove.

For Questions or comments contact:

Tinker & Rasor, P.O. Box 1667 San Bernardino, CA 92402-1667

Phone: (626) 287-5259

Web: www.tinker-rasor.com

E-mail: info@tinker-rasor.com www.teststations.com

E-mail: Info@tinker-rasor.com

QMF-570 010-163